t A	Scope of test	Measuring instrument/ Test connection	Operation/Requirement	Specified value	D Possible cause/Remedy
1.0	**Coolant level indicator electronic switch (S41)** **Model 163 as of 3.98**	S41 1 W B L 2	Ignition: **OFF** Disconnect coupling at S41, connect Ohm decade device, set 70 kW, Start engine, wait for up to 1min Set 30 kW wait for up to 1min	 Low ECL indicator lamp (A1e11) illuminated A1e11 goes out	Values in order: D Coolant level indicator electronic switch (S41) Values not in order: D Cables to A1 D A1

